


## **Ball Roll and Rebound tester**

The Ball Roll Ramp is used to test the ball roll distance on a synthetic turf pitch, this will give an indication of the condition of the carpet fibres. The integrated Drop Tester is used to test the level of re-bound in the surface to give an indication of surface hardness





## **Specifications**

SKU 191.100.000