

## Ball Roll and Rebound tester

The Ball Roll Ramp is used to test the ball roll distance on a synthetic turf pitch, this will give an indication of the condition of the carpet fibres. The integrated Drop Tester is used to test the level of re-bound in the surface to give an indication of surface hardness



### Specifications

SKU	191.100.000
-----	-------------